

Recommended Adhesives for CRAFT Flooring

CRAFT floors are warranted as per the standard *Creative At Home* Warranty if the following recommended adhesives are properly followed:

Adhesives for Glue-down Installations of Engineered Flooring

- For wider than 6" engineered flooring, installation MUST be either a nail and glue combination, or full glue spread installation.
- With nail and glue installations, a urethane wood flooring adhesive should be used. The glue should be applied in strips every 8 inches across the planks alternating with the nailing schedule, or as an "S" pattern down the length of the planks.
- With a full glue spread installation, a premium quality urethane adhesive is imperative.
Recommended adhesives are:

- Bostik BEST, or BST
- Mapei Eco 980, Eco 985, or Eco 995MB
- Franklin 811
- Stauf 850 or 455
- SikaBond T54, T55 or T21
- Bona R851

- For combination nail and glue installation, the recommended cartridge adhesives are: Bostik Best, Sika Construction, Mapei 905 and Bona 850T
- Please carefully follow the instructions of the adhesive manufacturer.
- With all flooring installation, we recommend Titebond adhesive for end-tongues and grooves only.

Note – It is strongly recommended to do a thorough test of the adhesive before proceeding to install the whole floor.